


GlobalSim


Quick Guide
Android

by Brightline Communications Pte Ltd


Making calls



Make call as per usual (e.g. from phone book or dialer)



Ignore 'Call Failed' message



Pickup incoming call. Your call will then be connected.


* ensure you always have the country code when making outgoing calls (e.g. +65 for Singapore)

Customer Service Hotline: +65 6336 2421 if you have any questions


Receiving Calls

To divert calls from your local mobile to the GlobalSim, follow the below steps



* Please take note that this should be done BEFORE you leave the country



go to **Phone** >
Call Settings >
Call Forwarding



select **Voice call** and then choose
Always forward



key in your assigned
singapore number


Customer Service Hotline: +65 6336 2421 if you have any questions




SMS

- Sending SMS as per usual
- Receiving SMS as per usual
- * The GlobalSim number will be reflected on your recipient's phone



Data Roaming Configuration



go to **Settings**
> **More Settings**
> **Mobile networks**



select **Access Point Names** and then
New APN



1. Key in APN as 'send.ee'
2. username to your GlobalSim number.
3. Password leave blank
4. Save and select the APN you just created

Customer Service Hotline: +65 6336 2421 if you have any questions